



49-3506



49-3507



3" Stretched Saddlebag Kit.

- Includes bags, lids, face plates, locks and mounting hardware.
- Bags are injection molded and have a smooth inside and outside surface. Bottoms are 2" deeper in the front, 3" deeper in the rear and have cutouts on both bags for dual exhaust.

VT No.	Fits
49-3506	1993-2013 FLT
49-3507	2014-up FLT



50-1135

50-1136

49-0468

Saddlebag Filler Panels

- These kits fill in the gaps between the fender and the rear of the saddlebags, hiding the saddlebag mounting brackets.
- Available in chrome or gloss black finishes and smooth for bikes without a saddlebag guard or slotted for bikes with saddlebag guards.

Chrome	Black	Fits/Years	Type
50-1135	50-1136	1993-08	Smooth
49-0468	49-0469	2009-13	Smooth
50-1196		2014-up	Smooth
50-1197		2014-up	Slotted



49-0535



49-0535

Black Saddlebag Bottom Set

- Constructed from a black PVC material, ready for primer and paint!
- Locks and hinges not included. Bags will accept OE or V-Twin lids and related hardware, available separately.
- All pieces are constructed of black fiberglass and reinforced FRP plastic, ready for primer and paint. FRP is made up of polyphenylene oxide/polyamide alloy.

VT No.	Fits
49-0535	1985-1992



42-1107

Saddlebag Filler Panels

- Fit 2006-2008 FLHX.

VT No.	Finish
42-1107	Chrome
42-1108	Raw



51-0480



49-0873

Chrome Saddlebag Support Set

- Left and right set used when saddlebag trim set are not used to create a cleaner custom appearance.

VT No.	Fits
51-0480	FLT 2009-2013, 90881-09A
49-0873	FLHX, FLTRX, FLT 2009-2013