



31-0927



31-1343



31-1027



31-1344

### Spotlamp Kit

• Fits 1996-up FLT-FLHT models.

Chrome	Black	Item
31-0927	31-1343	Bracket Set 2014-up
31-1027	31-1344	Bracket Set 1996-13

31-0482



31-0499



**Chrome Spotlamp Mount Bracket** is one piece type. Use VT No. 33-0010 Spotlamp.

VT No.	Fits
31-0482	1986-up FLHS
37-0552	Spacer for Above
31-0499	1994-01 FLHR, 1997-up FLHT

\*Note: Includes brackets which mount to lower pinch bolts.

31-0311



### Chrome V-Style Spotlamp Bracket

• Replace stock bracket.

VT No.	Year	Model
31-0311	1986-2001	FLST-FLSTF



31-1347



31-1349

**Spotlamp Brackets.** Clamp on style for engine guards, pair.

VT No.	Type
31-1347	Chrome, Fog Lamp Clamp 68000170
31-1348	Black Fog Lamp Clamp 68000142
31-1349	Chrome Fog Lamp Clamp 6800017
31-1350	Black, Fog Lamp 68000141



31-0830



31-0828



31-0829



31-0831



31-0833

### Spotlamp Eliminator Bracket Set.

Chrome	Black	Type
31-0830	31-0828	Ball Milled
31-0831	31-0829	Drilled
Carbon Fiber		
31-0833		Ball Milled



**Spotlamp Bracket Covers** feature textured surface and stepped design. Fits all 1996-13 FLT models. Replaces 68613-01.  
VT No. 42-0606