



51-0998



51-0853

### Passenger Footboard Sets with Swingarm Mount Kit

• Includes right & left side chrome pivot caps, passenger footboard mounts and passenger footboard with rubber pads.

VT No.	Footboard Style	Fits
51-0998	D-Shaped	FLT 2007-2008
51-0853	D-Shaped	FLT 1982-2006
51-0867	Mini	FLT 1982-2006



### Passenger Streamliner Style Footboard Set

• Includes rubber inserts. Order pins separately. Black finish. Fits 1993-up FLT.

VT No. 27-1762



### Chrome Passenger Footboard Set

• Without rubber inserts. Accepts black passenger footboard mat black, OEM #50606-86A, and passenger footboard pin kit, OEM #50933-86.

VT No. 27-0016



28-2120



28-2148

### Stock Black Rubber Passenger Footboard

• Fits factory passenger floor boards.  
• 1987-up FLT.

VT No.	Style
28-2120	Block, pair
28-2148	Ribbed, each