



27-0837

27-0837 Installed



27-0149



27-0148

Left Side Footboard Heel Guards

• Fit 1986-up FL style boards.

VT No.	Finish
27-0148	Chrome
27-0149	Black
27-0837	Chrome



27-1527



27-1526

Footboard Extender Kit

• Fits Touring. This kit is finished in black to extend footboards outward by 1¼" inches.

VT No.	Year
27-1527	1980-08
27-1526	2009-up



1" Footboard Extender

• Fits 1993-up FLT.

VT No. 27-1235



51-1601 Installed shown with 27-1235



27-0812



27-0811



27-1726



27-0811

Chrome Footboard Mount Set

• For FLT is a 4 piece set. Available in stock or +2" forward.

VT No.	Type	Finish	Year
27-1726	Stock	Chrome	1983-08
27-0811	+2"	Chrome	1983-08
27-0812	+2"	Black	1983-08
27-0827		Black	2009-up
27-1793	Stock	Chrome	2009-up



27-0162



27-0163



27-0863

Half Moon Footboard Set

• Features OE style pads and Iso mounted pads.

VT No.	Finish
27-0162	Black
27-0163	Chrome
27-0863	Trim



Footboard Forward Relocation Kit

• Re-mount footboards 1" forward on 1997 and later Touring models.

VT No. 27-1539