



Strut Set

50-1035



50-0899



50-1097



50-1092



50-1082



50-1093



50-0238



Chrome XL Fender Strut Sets are of a die cast alloy construction.

VT No.	OEM	Year	Item
50-1035	59950-89	1990-93	Set
	59951-89		
50-1142	—	1990-93	Set
50-0899	59950-81B	1982-89	Set
	59951-81		
50-1097	52754-79	1979-81	Set
	52755-79		
37-9084	Allen Bolt Set	1982-up	Set
33-0016	59259-90	1990-93	Reflector, Red



Chrome Strut Covers for Sportsters fit over existing stock struts.

VT No.	OEM	Years
50-1092	59243-95	1982-89
50-1082	59541-95	1990-93
50-1093	59897-94	1994-2003
50-0238	59902-04	2004-up
	59903-04	



50-1188



Rear Fender Black Struts. Constructed of die cast alloy.

VT No.	Fits
50-1187	1982-89 XLH
50-1188	1990-93 XL



Fender Rail Bolt Kits attach struts to the rear fender.

Stock	Acorn	Cap	Allen	Fits
8880-18	—	—	2529-6	1952-58 K and XLCH
2626-18	—	—	—	1952-58 XL (Cadmium)
8881-18	7207-8	8462-8	—	1959-81
2665-18	—	—	—	1959-81 (Cadmium)
—	—	—	37-9050	1957-78
—	—	—	37-9084	1982-03
—	—	—	2274-10	2004-up



Chrome Steel Fender Strut Sets available in smooth or stock style with or without turn signal holes.

Smooth	Stock	OEM	Year	Fits
50-0908	50-0904	59930-52B	1955-78 XL	Without signals
—	50-1034	59934-73	1973-78 XL	With signals