

# Gasket



## CAM COVER

GB No.	James	
15-0334	15-0277	24921-37
15-0564	—	25224-52A
15-0300	15-1077	25225-36A
15-0122	15-0928	25225-36C
15-0122	15-0928	25225-36C
15-0122	15-0928	25225-36B
15-0567	—	25225-36B
—	15-1267	25225-36X
15-0390	—	25225-36C
—	15-0929	25225-70A
15-0123	15-1141	25225-70B
15-0741	15-0713	25225-70X
—	15-1434	—
15-0692	15-0930	25225-93
—	15-0722	25225-93X
—	15-1435	—
15-0879	15-0286	25226-37A
15-0407	15-0276	25227-37
15-1501	15-1198	25244-99
—	15-1432	—
15-0153	15-1031	32521-36
15-0154	15-1031	32591-37
15-0339	15-0214	24978-57
15-0121	15-1078	25224-52A
15-0564	—	Pair
15-0124	15-0931	25263-81
15-0245	15-0932	25263-86
—	15-1433	—
15-0308	15-0933	25263-90A
15-0365	15-1223	25263-00

## PUSHROD TUBE

14-0501	14-0904	11101
14-0905	—	11101X
14-0508	—	11118
14-0512	—	11118
14-0514	—	11133
14-0513	—	11133A
14-0550	—	11145
14-0532	—	11157
14-0803	—	11293
15-0116	15-1137	17955-36
14-0028	—	—
15-0348	—	—
15-0117	15-1138	17955-48
14-0029	—	—
15-0349	—	—

## STARTER-GENERATOR

15-0217	15-1143	25811-11
15-0226	15-1021	30138-30
15-0287	15-1022	30143-30
15-0150	15-1023	30143-58
15-0566	—	30143-30
15-0410	—	31015-30
15-0655	15-1024	31320-80
15-0656	15-0966	31321-80
15-0174	15-0916	60518-65
15-0290	15-1064	60559-80
15-0181	15-0917	60645-65

## OIL PUMP

15-0306	—	24990-52
15-0310	—	24994-52
15-0299	15-0935	26231-78
15-0333	15-0275	26244-37
15-0727	—	26245-41
—	15-0126	26245-41
15-0338	15-0274	26246-37
15-0294	15-0940	26246-68A
—	15-0939	26246-68D
15-0127	15-0128	26255-41
15-0740	15-0130	26257-41
15-0131	15-0944	26257-50A
15-0134	15-0948	26258-69
15-0293	15-0949	26258-68B
15-0295	15-0953	26273-80A
15-0177	15-0954	26273-80B
15-0682	15-0954	26277-82
15-0198	15-0955	26276-80A
15-0296	15-0956	26276-80M
15-0683	15-0957	26276-92

## TAPPET GUIDE

15-0281	—	18245-39
15-0282	—	18257-39
15-0283	—	18259-39
14-0170	14-0621	18260-29
15-0255	—	18630-26
15-0330	15-0278	18631-30
15-0118	15-0925	18632-36
15-0119	15-0926	18633-48A
—	15-1438	18634-48
15-0120	15-0927	18634-48A
—	15-1439	18634-48
15-1542	—	—
—	15-1197	18635-99
—	15-1296	18635-99

## PRIMARY COVER GASKETS

—	15-1253	31434-06
15-0163	15-0909	34901-79
15-0743	15-1115	34901-85
15-0239	15-0904	34901-85
15-0050	—	—
15-0967	15-0937	34901-94A
15-0051	15-1336	—
15-1512	—	34901-07
15-1547	—	34901-07
15-0164	15-1080	34902-79A
15-0165	15-1081	34903-79
15-0229	—	60538-81
15-0176	15-0906	60538-81C
15-0401	15-0900	—
—	15-1338	—
15-0645	—	60539-89
15-0677	15-0902	60539-89X
15-0404	15-0921	60539-94
15-0452	15-1337	—
15-0175	15-0905	—
15-0644	15-1128	60540-36
15-0400	—	60540-65
15-1510	15-1254	60540-65A
15-1525	—	60547-06

1937-73 Flathead Cam Cover Breather  
 1952-56 K, 1957-80 XL  
 1936-40 Knucklehead  
 1941-69 Big Twin  
 1941-47 Knucklehead  
 1941-62 Big Twin  
 1936-47 Big Twin  
 As Above with Silicone Bead  
 1963-69 Big Twin  
 1970-92 Big Twin (white .030")  
 1970-92 Big Twin (black)  
 1970-92 Big Twin with Silicone  
 As Above Foamet® with Silicone Bead  
 1993-99 80" Evolution Big Twin, Black  
 1993-99 80" Evolution Big Twin with silicone  
 As Above Foamet® with Silicone Bead  
 1937-73 45" Flathead  
 1937-48 74" /80" Flathead  
 1999-up Twin Cam 88 Cam Cover Gasket  
 As Above Foamet® with Silicone Bead  
 BT OHV Knuckle Circuit Breaker Base  
 UL and 45 Circuit Breaker Base  
 1957-81 Oil Strainer  
 1954-Early 81 XL Cam Cover  
 1954-Early 81 XL Cam Cover  
 1982-85 XL Cam Cover  
 1986-90 XL Cam Cover  
 1986-90 XL Cam Cover Foamet®  
 1991-up XL Cam Cover  
 2000-up XL Cam Cover w/Bead

Late 1979-E81 Upper O-Ring  
 Late 1979-81 Upper O-Ring (oversized)  
 Late 1979-81 Upper Quad Seal  
 Late 1979-2000 Middle O-Ring  
 Late 1979-E81 Lower O-Ring  
 Late 1981-84 Lower Quad Seal  
 1984-2000 Lower O-Ring  
 1984-99 80" Evolution Upper O-Ring  
 1999-2000 Twin Cam 88 Upper O-Ring  
 1936-Early 79 Small Cork  
 As Above Silicone  
 As Above Rubber  
 1948-Early 79 Large Cork  
 As Above Silicone  
 As Above Rubber

Generator stud washer for 1911-85 FL  
 1937-48 Generator End Cover  
 1930-57 Generator Mount Gasket  
 1958-69 Generator Mounting  
 Generator Gasket  
 1930-64 Generator Bearing End  
 1980-86 Belt Drive Starter Housing to Primary  
 1980-86 Belt Drive Starter (between two housings)  
 1965-86 Starter Hole Cover with Kicker only  
 1980-85 Chain Drive Starter Housing Oil Deflector Plate  
 Late 1965-88 Solenoid

1952-57 Tappet Oil Screen Plug  
 1952-92 Tappet Oil Screen Plug  
 1954-80 Oil Pump Cap Washer Blue Teflon  
 1937-59 W/WLA Body to Motor  
 1941-67 FL Oil Pump Body to Case (Mylar)  
 As Above Paper  
 Side Valve Scavenger Pump Base  
 1968-80 Body to Motor, Mylar  
 1968-Early 80 Body to Motor, Paper  
 1941-Early 50 Cover (Governor Fitted), Paper  
 1941-Early 50 Cover, Black Paper  
 Late 1950-67 Cover, Black Paper  
 1968-Early 80 Cover, Black Paper  
 1968-Early 80 Cover, Mylar  
 Late 1960-91 Body to Motor, Mylar  
 Late 1960-91 Body to Motor, Black Paper  
 1992-99 80" Evolution Body to Motor, Black Paper  
 Late 1980-91 Cover, Black Paper  
 Late 1980-91 Pump Cover, Mylar  
 1992-99 80" Evolution Cover, Black Paper

1939-48 Flathead Upper Guide Cover  
 1939-48 Flathead Lower Guide Cover  
 1936-48 Tappet Block Fiber Washer  
 1929-68 Flathead Valve Spring Cover Seal  
 1926-73 45" Flathead Spring Cover  
 1930-73 Flatheads, Tappet Guide  
 1936-47 Overhead Valve Tappet Guide  
 1948-99 Rear Tappet Guide  
 1948-99 Rear Tappet Guide Foamet®  
 1948-99 Front Tappet Guide  
 1941-48 Front Tappet Guide Foamet®  
 1948-99 Set  
 1999-2000 Twin Cam 88 Tappet Cover Gasket  
 1999-up Twin Cam 88 Tappet Cover Gasket with Foamet®

2007-up Big Twin Inner Primary Mounting Bolt  
 1980-93 FXR/FLT Primary Cover (.030")  
 1980-93 FXR/FLT Primary Cover (.062")  
 1983-93 FXR/FLT Primary Cover (.062"), Beaded  
 As Above Metal with Foam Rubber Coating  
 1994-2006 FXR/FLT Primary Cover  
 As Above Metal with Foam Rubber Coating  
 2007-up FLT, Touring  
 2007-up FLT  
 1980-84 FXR/FLT Primary to Trans (large)  
 1980-84 FXR/FLT Primary to Trans (small)  
 1982-88 Rigid Mount Primary Cover 1/16" thick 9 hole  
 As Above 1/32" thick  
 Late 1982-88 Rigid Mount 9 Hole Primary, Beaded  
 As Above, Foamet® with bead  
 1989-93 Softail, Dyna Primary Cover (.062)  
 1989-93 Softail, Dyna Primary Cover, Beaded  
 1994-06 Softail, Dyna Primary Cover Beaded  
 As Above Metal with Foam Rubber Coating  
 1936-64 Primary Cover, cork  
 1965-80 FX/FL Primary Cover (8 hole)  
 1965-82 4 Speed, 8 hole Primary Cover Beaded  
 2006-up FXD Beaded, 2007-up FXST Primary Cover Beaded  
 Inner Primary Gasket

