



Primary



Outer Primary Cover Starter Bearing Removal Tool removes 9063 Torrington Needle Bearing for Big Twin and XL covers. **VT No. 16-0717**
Note: This tool will also remove the 35961-52 Bearing in Countershaft Gear (Late) 4 Speed Big Twin, and also the 4-Speed Sportster Clutch Gear.



Big Twin Primary Drive Locking Tool is used as a wedge type device to hold the primary drive gear while the proper torque is applied without damaging the primary gear. Constructed of nylon, OEM# 41214.
VT No. 16-0650




Ratchet Plate Riveting Fixture securely aligns plate to drum while setting rivets on 1971-79 XL model clutch drum.
VT No. 16-0165



Starter Jackshaft Seal Installer Tool will easily allow alignment and installation of starter jackshaft seal (OEM#12066) without distortion or damage to seal. For 1994-06 Big Twins except 2006 Dynaglide.
VT No. 16-1373



Inner Primary Cover Bearing and Seal Remover Installer Tool safely removes and installs inner primary bearing (OEM# 9135) without damage to the new bearing by pushing on the outer perimeter of the bearing. Removes and installs inner primary and seal that the transmission mainshaft passes through (OEM#12052A). For L1984-06 FXST/FLT; 85-up FLT/FLHT/FXR/FXD/FXDWG.
16-1367 1984-06
16-1027 2007-up



Primary Locking Bars use to lock primary for servicing.

VT No.	Use
16-0680	4-Speed BT's and 5-Speed FXST
16-0681	5-Speed FXR-FLT
16-0682	1991-up Sportster and Buell*
16-1357	2007-up Dyna
16-0327	2007-up FLT



Clutch Adjusting Gauges are used to find the correct distance between the outer drive plate and outer releasing disc for 1971-83 Sportsters, 1936-67 early and 1968-84 late Big Twins. Set of 3 tools. **VT No. 16-1807**



Starter Pinion Gear Holder Tool fits 9 and 10 tooth gears.
VT No. 16-0484



Starter Ring Gear Rivet Fixture Tool removes the starter ring gear rivets from Big Twin clutch shells. For 2006-07 Big Twin except Dyna.
VT No. 16-1368



Primary Plug Wrenches for Sportster models.

VT No.	OEM	Years
16-0158		1971-84
16-0985*	33186	1971-up
8862-1	Evolution	1986-up
8862-1T	Evolution	1986-up

*Note: Uses 3/8 socket handle

Belt



Final Drive Tool fits final drive pulley, so the nut can be properly set to torque specifications.

VT No.	Type
16-0649	Big Twin
16-0588	XL



Belt Tension Gauge designed to aid in properly adjusting belt tension on models with a secondary drive belt.
VT No. 16-1765




Calibrated Belt Tension Gauge. Accurately measures belt tension.
VT No. 16-0589


Chain



Standard Chain Puller eliminates the annoyances of installing the master link in rear chain. Conveniently pulls chain halves together without loosening at rear wheel. Fits all sizes.
VT No. 16-0611



Chain Puller Tool.
VT No. 16-1615



Diamond Chain Breaker is excellent for cutting 530 heavy chain.
VT No. 16-0255



Link Press Tool presses the side plates on all 530 O-Ring Chains.
VT No. 16-1729



Small Chain Breaker replaces 12039X.
VT No. 16-0144

Chain Riveting Tool and Chain Breaker.
VT No. Item
16-1740 Breaker
16-1741 Riveting Tool Set
16-0201 Riveting Tool Set (V-Twin)